

## **Audio Checklist**

### *Power controls above audio board:*

Turn power on

Press the sticker-marked “VTR” button

The sticker-marked “Volume” controls speaker sound in the control room

### *The audio board:*

Set the Left-Right Master Volumes to 0 (Located far lower right of the board).

Select PWR +48 for Mics, LINE for all other sources (at top of board).

Assign each audio channel to the Master by pressing the white L-R button in.

Raise the White Fader of each channel being used.

Monitor audio with meter on the board or use Record Deck volume needles.

### *Notes:*

- if you don't hear audio, make sure the record deck is stopped.
- Black 3-4 controls send audio into the studio. Masters are on right side.